



YOU WILL NEED:




Pegboard:


- Small hexagon

Other:

- Ironing paper
- Scissors
- Round beads: cream
- White waxed linen cord
- Thin jute cord

Bead Colors:

-  Cheddar - 28
-  Light Brown - 24
-  Black - 13



Instructions

1. Place your beads on the pegboard as shown.
2. Ask an adult to fuse your designs—see below for further instructions.

Assembly

3. Thread a 40" piece of white waxed linen cord through the top yellow bead on the pendant. Secure in place by tying the cord into a double knot. Thread one black bead both ends of the cord. Slide the black bead to the top of the pendant and knot.
4. Spread apart the two pieces of cord to create the left and right sides of the necklace. Working on one side of the necklace, slide beads onto the cord and all the way down to the pendant in this order: black, light brown and yellow. Knot the cord to hold the three beads in place. Place the cord and beads on a heat safe surface. Using ironing paper and just the tip of the iron, fuse the three colors together. Let cool then flip the beads over and repeat. This process will create a tri-colored bead.
5. Next, place a round bead on the cord and knot to secure. Repeat steps 4 and 5 until both sides of the necklace have the desired number of beads. Leaving a few inches for a tie closure, trim excess cord.
6. Cut an 8" length of jute cord and wrap it around the pendant a few times to accent it. Knot the ends in a square knot and trim excess cord.



Fusing Instructions—Only Adults Iron



1. Place your pegboard on a flat, heat-safe surface.
2. Set a household iron to the medium setting. Place ironing paper over the pegboard. In a circular motion, begin to iron the project. Do not press down with the iron. As the beads begin to fuse, you will see circles of the beads start to show through the paper. When ironed properly, the beads will still have an open center. Let the design cool.
3. Remove the paper and bead design from the peg board. Flip the design over to expose the non-fused side. Repeat step two. Let cool completely.

NOTE: Beads need heat for about 10-20 seconds per side to fuse evenly. Lift the

paper occasionally to see how the beads are fusing. Depending on the size of the project, additional heating time may be required. **DO NOT OVER-IRON** the beads as it will make the centers of the beads close and can make any assembly you do with your project more challenging.